



- NOTES:
1. ALL AC WIRING MUST BE 14 AWG OR LARGER.
 2. WIRE EACH AC GROUND CONNECTION TO GROUNDING BOLT. BOLT MUST NOT BE USED FOR ANY OTHER PURPOSE.
 3. RUN ONE WIRE FROM TB1-4 TO GROUNDING BOLT.
 4. MOUNT AC FUSES AND LEDS ON FRONT PANAL.

REVISIONS http://loel.ucolick.org/manual/Apf/schematics/8_Channel_AC_Controller_sh_1.pdf
 04-27-10 CORRECTED WEB FILENAME

UNIVERSITY OF CALIFORNIA LICK OBSERVATORY		8-CHANNEL AC POWER CONTROLLER	
DES'N BY: B. Alcott	ORIGIN DATE: 08-29-05	DWG. NO.	NUM. 1 OF 2
Last SN	MODIFY DATE: 04-27-10	EL-1398	REV. A
PRINT TIME: 10:06:41	PRINT DATE: Tue Apr 27, 2010		
PATH: APF/		8_Channel_AC_Controller.sch	