

SHANE AO Drawings

EL-	PCAD FILE	DESCRIPTION	
3800	SAO\3500	THIS INDEX	
3801	SAO\SAO_block	Electronics block diagram	
3802	SAO\SAO_in_out	I/O signal assignments	
3803	SAO\SAO_--	--	
3804	SAO\SAO_--	--	
3805	SAO\SAO_--	--	
3806	SAO\SAO_--	--	
3807	SAO\SAO_--	--	
3808	SAO\SAO_--	--	
3809	SAO\SAO_--	--	
3810	SAO\SAO_--	--	
3811	SAO\SAO_calibration	Calibration stage	Servo, Pico
3812	SAO\SAO_fm1	Fold mirror #1, tip and tilt	2 Servo
3813	SAO\SAO_fm3	Fold mirror #3, tip, tilt, and piston	3 Pico
3814	SAO\SAO_ircal_filter	IRCAL Filter wheel	Filter wheel
3815	SAO\SAO_tt_x-y	TT stage X-Y stage	2 Brushless
3816	SAO\SAO_tt_dichroic	TT Dichroic stage	Servo
3817	SAO\SAO_tt_filter	TT Filter wheel	Filter wheel
3818	SAO\SAO_waveplate	Waveplate insertion and rotation stages	2 Servo
3819	SAO\SAO_WFS	WFS camera stage	3 Servo, 2 Pico
3820	SAO\SAO_wfs_dichroic	WFS camera dichroic	Servo
3821	SAO\SAO_wfs_filter	WFS Filter wheel	Filter wheel
3822	SAO\SAO_wfs_fs1	WFS field steering mirror #1	2 Servo
3823	SAO\SAO_wfs_fs2	WFS field steering mirror #2	2 Servo
3824	SAO\SAO_mems_stages	MEMS 5-axis stage	5 Pico
3825	SAO\SAO_--	--	
3826	SAO\SAO_--	--	
3827	SAO\SAO_--	--	
3828	SAO\SAO_--	--	
3829	SAO\SAO_--	--	
3830	SAO\SAO_--	--	
3831	SAO\SAO_--	--	
3832	SAO\SAO_--	--	
3833	SAO\SAO_--	--	
3834	SAO\SAO_--	--	
3835	SAO\SAO_--	--	
3836	SAO\SAO_--	--	